
Data Collection System (DCS) 3000

User Guide

Chapter 6

Software Version Numbers: MultiServer V 1.5J

Using the DCS MultiServer

The MultiServer performs many functions during electronic surveillance operations. Step-by-step procedures of the MultiServer are presented in the following sections:


- Working in the MultiServer Window
- Setting up a Switch
- Monitoring Activity
- Storing Target Data Files
- Shutting Down the MultiServer
- Quick Steps

Once connected, the MultiServer receives all information on a target generated by the switch.

ALL INFORMATION CONTAINED
HEREIN IS UNCLASSIFIED
DATE 05-22-2007 BY 65179 DMH/TAM/KSR/cb

b2
b7E


Working in the MultiServer Window



To clear detail messages from the MultiServer window:




To cut a text selection:



b2
b7E




To copy a text selection:



b2
b7E




To cut all text:




b2
b7E



To copy all text:



Setting up a Switch



b2
b7E




Figure 6-1: DCS MultiServer Configuration Window – Add and Edit Buttons Displayed

The steps for manually connecting the MultiServer are presented as follows:

- Adding a connection
- Editing a connection
- Deleting a connection
- Establishing a connection
- Configuring a connection

b2
b7E

To Add a Connection



To set up a connection in the MultiServer:

Password:
Enter Configuration Password

b2
b7E



Name	Switch	Con.	Version	IPAd.	Ren.	Lo.	Conn.
[Redacted]							

Buttons: Add, Edit, Delete, Connect, Disconnect


b2
b7E



b2
b7E



Note:





b2
b7E

Note:




To Edit a Connection




b2
b7E



To modify an existing connection:




b2
b7E





b2
b7E



b2
b7E






Note:



b2
b7E



Note:




To Delete a Connection

b2
b7E



To delete a connection:

b2
b7E





b2
b7E



Note:



b2
b7E





b2
b7E




~~2~~ Note:




To Establish a Connection

b2
b7E



To request a connection to a switch:

b2
b7E



- OR -




Password

 Enter Configuration Password



b2
b7E



 Note:



To disconnect all switches:




Password

 Enter Configuration Password

b2
b7E





b2
b7E




Note:



To disconnect one switch:

b2
b7E





b2
b7E



Note:




To Configure a Connection

b2
b7E





The switches supported by the MultiServer are presented as follows:

b2
b7E



b2
b7E



b2
b7E






Figure 6-2: DCS MultiServer Configuration Window



To configure the MultiServer for [redacted] with a TCP/IP connection:

b2
b7E






b2
b7E



b2
b7E




b2
b7E





Note:



b2
b7E



Note:



To configure the MultiServer for  with a Serial connection:



b2
b7E






b2
b7E

A screenshot of a dialog box with a grid background. It contains the following fields:

- Connection Type:** A dropdown menu with options: TCP/IP, Serial, and Tera. The 'Serial' option is selected.
- Ericsson Revision:** A dropdown menu.
- Number To Dial:** A text input field.
- Password:** A text input field.
- Wait to Connect for:** A text input field followed by the word "Seconds".
- Modem:** A dropdown menu.



b2
b7E

A screenshot of a dialog box titled "Ericsson Modem Settings" with a grid background. It contains the following fields:


- Connect Using:** A dropdown menu.
- Base Rate:** A dropdown menu.
- Parity:** A dropdown menu.
- Data Bits:** A dropdown menu.
- Stop Bits:** A dropdown menu.
- Direct Connect:** A checkbox.
- HW Flow Control:** A checkbox.
- Buttons:** "Ok", "Done", "Direct Connect", and "HW Flow Control".



b2
b7E



Note:



b2
b7E



Note:





To configure the MultiServer for [redacted] with a Telnet connection:

[redacted]

[redacted]

[redacted]

[redacted]

[redacted]

b2
b7E

Connection Type	[redacted]	Revision	[redacted]
TCP/IP	<input type="checkbox"/>		
Serial	<input type="checkbox"/>		
Telnet	<input checked="" type="checkbox"/>	Log	<input type="checkbox"/>
Telnet IP Address	[redacted]	Telnet Ping Address	[redacted]
Telnet User Name	[redacted]	Telnet Password	[redacted]
Telnet Socket	[redacted]	Telnet Command Line	<input type="checkbox"/> Terminal Server

[redacted]

[redacted]


[redacted]

[redacted]

b2
b7E




b2
b7E



b2
b7E




Note:





b2
b7E

Note:



b2
b7E

The screenshot shows the 'DCS MultiServer Configuration Window'. At the top, there is a 'Switch Manufacturer' section with radio buttons for 'Eaton', 'Newell', 'Nokia', 'Jed 25', and 'Vendor'. Below this is a 'Connection Name' field and a 'Ping' checkbox. The 'Connection Type' section has a dropdown menu set to 'TCP/IP' and a 'Override "Called Number"' checkbox. The 'Specialized Connections' section includes checkboxes for 'Daily' and 'Client Request'. Other fields include 'TCP Address', 'TCP Port Number', 'Binding Port', and 'Ring Address', all of which are redacted with black boxes.

Figure 6-3: DCS MultiServer Configuration Window





To configure the MultiServer for [redacted] with a TCP/IP connection:

[redacted]

[redacted]

[redacted]

[redacted]

[redacted]

b2
b7E

Connection Type		[redacted]
<input checked="" type="radio"/> TCP/IP	<input type="radio"/> Serial Port	[redacted] [redacted]
		<input type="checkbox"/> Enable "Called Number"
TCP Address	[redacted]	Specialized Connections
TCP Port Number	[redacted]	<input type="checkbox"/> Daily
Binding Port	[redacted]	<input type="checkbox"/> Client Request
Prog Address	[redacted]	


[redacted]

[redacted]



[redacted]

[redacted]

b2
b7E



b2
b7E




Note:



b2
b7E



Note:





b2
b7E


Note:




To configure the MultiServer for  with a Serial connection:



b2
b7E






b2
b7E

Connector Type			
<input type="checkbox"/> TCP/IP	<input type="checkbox"/> Serial Port	<input type="checkbox"/> Ethernet	<input type="checkbox"/> Credit Number
Number To Dial			
Password			
Wait to Connect for			Seconds



b2
b7E



b2
b7E



Note:




b2
b7E





Note:




b2
b7E



Note:



b2
b7E




b2
b7E


Figure 6-4: DCS MultiServer Configuration Window




To configure the MultiServer for [redacted] with a Serial connection:




b2
b7E

A screenshot of a dialog box titled "Connection Type". It features a "Serial" radio button which is selected, and a "Modem" radio button which is unselected. Below these are fields for "Number To Dial", "Password", and "Wait to Connect for" (with a "Seconds" label). A "Modem" label is also present at the bottom right of the dialog box.


b2
b7E



b2
b7E



b2
b7E



Note:




b2
b7E





Note:



b2
b7E



Note:



To configure the MultiServer for  with a Telnet connection:




b2
b7E






b2
b7E


Connection Type		
<input type="checkbox"/> Serial	<input type="checkbox"/> Telnet	<input type="checkbox"/> Log
		<input type="checkbox"/> Tone Enabled
Telnet IP Address		Telnet Ping Address
Telnet User Name		Telnet Password
Telnet Socket	Telnet Command Line	<input type="checkbox"/> Terminal Server



b2
b7E




b2
b7E



b2
b7E



J-STD-025 Settings



b2
b7E

Switch Manufacturer

Connection Name: _____ Ping:

Connection Type:

Override Called Number
 ASCII SMS


TCP Address: _____
TCP Port Number: _____
Binding Port: _____
Ping Address: _____

Modem Guard or Atlas
 Keep Alive
 Special Connection


Figure 6-5: DCS MultiServer Configuration Window - J-STD-025 Settings



To configure the MultiServer for J-STD-025 25 Standard switch with a TCP/IP connection:




b2
b7E




b2
b7E



Connection Type		Jxd 25 Version	
<input checked="" type="radio"/> TCP/IP	<input type="checkbox"/> Serial	<input type="checkbox"/> Override Called Number	<input type="checkbox"/> ASCII SMS
<input type="checkbox"/> IP Port	<input type="checkbox"/> Serial Port		
IP Address	<input type="text"/>	<input checked="" type="checkbox"/> AMGuard or Alias <input type="checkbox"/> Keep Alive <input type="checkbox"/> Special Connector	
TCP Port Number	<input type="text"/>		
Binding Port	<input type="text"/>		
Eng Address	<input type="text"/>		

b2
b7E






b2
b7E



b2
b7E

Note:
[Redacted]





Note:




b2
b7E




Note:



To configure the MultiServer for J-STD-025 switch with a Serial connection:



b2
b7E



b2
b7E



Connection Type		Send 25 Version	
<input type="checkbox"/> HTTP	<input type="checkbox"/> Serial Port	<input type="checkbox"/> Diverse Call Number	<input type="checkbox"/> ASCII SMB
<input type="checkbox"/> Serial	<input type="checkbox"/> Serial Pod		
Number To Dial	<input type="text"/>	<input type="checkbox"/> Workaround Enabled	
Password	<input type="text"/>	<input type="checkbox"/> Keepalive	
Wait to Connect for	<input type="text"/> Seconds	<input type="checkbox"/> Escalate to Admin	

b2
b7E





b2
b7E




Note:



b2
b7E





Note:



b2
b7E




Note:



To configure the MultiServer for J-STD-025 switch with a GR30 connection:

b2
b7E







Connection Type		Modem 255 Version	
<input type="checkbox"/> GP/IP	<input type="checkbox"/> Serial Port	<input type="checkbox"/> 115200/8E/23/20/Normal	<input type="checkbox"/> ASCII SMS
GP 30	GP 30	Modem Timeout: <input type="text" value="0"/> minutes <small>0 value disables timeout</small>	<input type="checkbox"/> Authorized Caller ID
<input type="checkbox"/> Login ID: <input type="text"/>	<input type="checkbox"/> Old	<input type="checkbox"/> New	<input type="text"/>
ACK/NAK: <input type="radio"/> Yes <input type="radio"/> No	Modem Firmware: <input type="radio"/> Old <input type="radio"/> New		<input type="checkbox"/> Handup On OK-String
<input type="checkbox"/> Handup On OK-String	Ring Down: <input type="checkbox"/>	[+] [-]	

b2
b7E





b2
b7E







b2
b7E

Note:





b2
b7E





b2
b7E


Note:



b2
b7E

Note:





b2
b7E






Figure 8-7: DCS MultiServer Configuration Window



To configure the MultiServer for a [redacted] with a TCP/IP connection:




b2
b7E





b2
b7E

<input type="checkbox"/>	ICP/P	
TCP Address	<input type="text"/>	<input type="text"/>
TCP Port Number	<input type="text"/>	<input type="text"/>
Binding Port	<input type="text"/>	<input type="text"/>
Ping Address	<input type="text"/>	<input type="text"/>



b2
b7E





Note:




b2
b7E



Note:



Monitoring Activity



b2
b7E

Figure 6-8: MultiServer Window – Messages Tracking Activity

This table describes some messages that may appear in the MultiServer window.

Message	Description
[Client Name] Client Connected	
Switch: Connected: 0 Connecting: 0 [1]	
Switch: Connected: 1 Connecting: 0 [1]	
Switch: Connected: 0 Connecting: 1 [1]	
Sent Message: Nortel GSM ccOpen Message	
[Client Name] Client Disconnected	
[Switch Name] Switch: Disconnected	


b2
b7E




b2
b7E



To verify recent switch activity:




b2
b7E







b2
b7E





b2
b7E






To track recent target activity:



b2
b7E





Target Check


MSISDN Target

Client: Target:

OK Cancel

b2
b7E

Note:




Storing Target Data Files



b2
b7E




 **Note:**







To save a log file to a designated drive:





b2
b7E








b2
b7E




b2
b7E





b2
b7E




Note:








To remove a log file from the buffer:





b2
b7E





b2
b7E





b2
b7E



Note:



b2
b7E

Shutting Down the MultiServer



To shut down the MultiServer:



Quick Steps: DCS MultiServer

Working in the MultiServer Window

To clear detail messages from the MultiServer window:



To cut a text selection:



To copy a text selection:



To cut all text:




To copy all text:




b2
b7E

Setting up a Switch

To Add a connection:




To Edit a connection:




b2
b7E

To Delete a connection:




To Establish a Connection:



b2
b7E

To Disconnect all switches:



To Disconnect one switch:


b2
b7E



Setting up a Switch





To configure the MultiServer for an [redacted] with a TCP/IP connection:




b2
b7E

To configure the MultiServer for an [redacted] with a Serial connection:






To configure the MultiServer for an with a Telnet connection:




b2
b7E

Setting up a Switch -

To configure the MultiServer for a with a TCP/IP connection:




b2
b7E



To configure the MultiServer for a [redacted] with a Serial connection:


b2
b7E



Setting up a Switch -


[Redacted]


To configure the MultiServer for a [Redacted] with a Serial connection:



b2
b7E

To configure the MultiServer for an [Redacted] with a Telnet connection:






b2
b7E


Setting up a Switch – J-STD-025 Connections

To configure the MultiServer for a J-STD-025 switch with a TCP/IP connection:




To configure the MultiServer for a J-STD-025 switch with a Serial connection:






To configure the MultiServer for a J-STD-025 switch with a GR30 connection:

b2
b7E






To configure the MultiServer for a  with a TCP/IP connection:




b2
b7E

Monitoring Calls

To verify recent switch activity:



To verify recent Target activity:




Storing Target Data Files

To save a log file to a designated drive:



To remove a log from the buffer:



b2
b7E

Shutting Down the MultiServer

To shut down the MultiServer:

