

The Wasp Air Vehicle is equipped with four channels/frequencies to allow multiple systems to operate in proximity. However, it is recommended that systems operate no closer to one another than 400 meters. See Section 5.2.14 for more information on operating multiple systems in proximity. The channels operate at the frequencies listed in Table 1-4.

Table 1-4 BATMAV Frequencies

Channel	Uplink (MHz)	Downlink (MHz)
1	395.000	1787.5
2	395.050	1810.0
3	395.100	1840.0
4	394.950	1760.0